#### INITIAL CONSTRUCTION CLEAN

- Sweep, mop sweep or dry vacuum the floor to remove dust, grit and debris.
- Apply a solution of alkaline cleanser, diluted to the manufacturer's
  instructions, to the floor and leave for sufficient time to react with the
  soiling. Using a 165 rpm rotary machine fitted with a rotary scrubbing
  brush or, if necessary, a scrubbing pad, machine scrub the floor and then
  pick up the slurry with a wet vacuum. Rinse the floor thoroughly with
  clean, warm water, pick up with a wet vacuum and leave to dry thoroughly.
- Note 1: For small areas, where there is no suitable scrubbing machine available, a deck scrubber should be used in conjunction with a wet vacuum or mop and bucket system.
- Note 2: For very heavy soiling, dilution rates above the manufacturer's minimum recommendations may be necessary.
- Note 3: For Polysafe Hydro and Hydro Evolve, the scrubbing pad should be replaced with a rotary scrubbing brush or a cylindrical type scrubbing machine.



### **ROUTINE MAINTENANCE**

 The frequency of each of the operations is dependent upon the type and intensity of traffic.

### STANDARD SURFACE FINISH

- Sweep, mop sweep or dry vacuum the floor to remove dust and loose dirt.
- Spot mop regularly. Stubborn black marks can be removed by using the centre disc of a scrubbing pad and a small amount of undiluted alkaline cleanser. Place the disc under the sole of a shoe and rub - this gives greater pressure. Rinse the area well with clean warm water and leave to dry.
- Apply a solution of neutral or alkaline cleanser, diluted to the
  manufacturer's instructions, to the floor and leave for sufficient time
  to react with the soiling. Using a 165 rpm rotary machine fitted with a
  rotary scrubbing brush or, if necessary, a scrubbing pad, machine scrub
  the floor and then pick up the slurry with a wet vacuum. Rinse
  thoroughly with clean, warm water, pick up with a wet vacuum and leave
  to dry thoroughly.

### POLYSAFE HYDRO AND HYDRO EVOLVE

- Sweep, mop sweep or dry vacuum the floor to remove dust and loose dirt.
- Spot scrub regularly with a deck scrubber.
- Apply a solution of neutral or alkaline cleanser, diluted to the
  manufacturer's instructions, to the floor and leave for sufficient time
  to react with the soiling. Using a 165 rpm rotary machine fitted with a
  bristle brush, cylindrical machine or deck scrubber, scrub the floor and
  then pick up the slurry with a wet vacuum. Rinse thoroughly with clean,
  warm water, pick up with a wet vacuum and leave to dry thoroughly.



## APPLICATION OF A FLOOR DRESSING

 A floor dressing or maintainer containing polish should not be applied to the Polysafe ranges, as this may impair the slip resistance but, if in doubt, consult our Technical Support staff.



- Always follow the Health and Safety guidance provided.
   REGULAR CLEANING IS MORE BENEFICIAL TO THE FLOORCOVERING AND MORE COST-EFFECTIVE THAN OCCASIONAL HEAVY CLEANING.
- Cleaners and detergents should be diluted as per the manufacturers' instructions. For recommended products, see the Polyflor Approved Maintenance Products sheet located within the Technical section of www.polyflor.com.
- Polysafe safety flooring ranges are compatible for use with the most commonly used alco-based hand gels and are suitable for steam cleaning on a periodic basis.
- For further clarification and advice on specific applications, consult Polyflor Customer Technical Services on +44 (0)161 767 1912, or email tech@polyflor.com.



# SAFETY FLOORING

FLOORCARE FOR
POLYSAFE RANGES
ECOMAX,
STRATA,
ULTIMA,
APEX,
HYDRO AND
HYDRO EVOLVE.

POLYFLOR LTD. PO BOX 3 RADCLIFFE NEW ROAD WHITEFIELD MANCHESTER M45 7NR UK SALES DIRECT: +44 (0)161 767 1122 UK SAMPLE REQUESTS: +44 (0)161 767 2551 EXPORT SALES DIRECT: +44 (0)161 767 1913 TECHNICAL SUPPORT: +44 (0)161 767 1912 RECEPTION: +44 (0)161 767 1111 UK FAX: +44 (0)161 767 1128 EXPORT FAX: +44 (0)161 767 1166

E-MAIL: INFO@POLYFLOR.COM WWW.POLYFLOR.COM



