



# Polyflor Canada Approved Adhesives

	HORIZONTAL BOND	HORIZONTAL BOND HIGH TEMPERATURE / *EXTREME CONDITIONS	VERTICAL BOND
<b>HOMOGENOUS - NON DIRECTIONAL</b>			
<b>PALETTONE PUR / PEARLAZZO PUR / PRESTIGE PUR / CLASSIC MYSTIQUE PUR</b>			
<b>Mapei</b>	Ultrabond ECO 360 / 350 / 307 / 399	Ultrabond G21 / G19 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S	KR 430 / KE 66	KE2000S/WK222 / U-Tack Adhesive Tape
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46 / F58 Plus	F73 Plus	F60 / F66
<b>Wakol</b>	D 3318 / D3320	MS 552 / PU 270	-

	HORIZONTAL BOND	HORIZONTAL BOND HIGH TEMPERATURE / *EXTREME CONDITIONS	VERTICAL BOND
<b>HOMOGENEOUS - MARBLEISED</b>			
<b>2000 / XL PU / STANDARD XL</b>			
<b>Mapei</b>	Ultrabond ECO 360 / 350 / 307 / 399	Ultrabond G21 / G19 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S	KR 430 / KE 66	KE2000S / WK222/ U-Tack Adhesive tape
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46 / F58 Plus	F73 Plus	F60 / F66
<b>Wakol</b>	D 3318 / D3320	MS 552 / PU 270	-

## HETEROGENEOUS FLOORING

FOREST FX			
Mapei	Ultrabond ECO 360 / 399	Ultrabond G21 / MS 4 LVT	Ultrabond ECO 399
Uzin	KE 2000S	KR 430 / KE 66	KE2000S / WK222 / U-Tack Adhesive tape
Henry	695 / 422	2575 MS	2575 MS
F. Ball	F44 / F46	F73 Plus	F66
Wakol	D 3318 / D3320	MS 552 / PU 270	-
BLOC PUR			
Mapei	Ultrabond ECO 399	Ultrabond G21 / G19 / MS 4 LVT	-
Uzin	KE 2000S	KR 430 / KE 66	KE2000S / WK222 / U-Tack Adhesive tape
Henry	695 / 422	-	2575 MS
F. Ball	F46	-	F66
Wakol	D 3330*	-	D 3330

## ACOUSTIC FLOORING

ACOUSTIX FOREST FX PUR			
Mapei	Ultrabond ECO 360 / 399	Ultrabond G21	Water based contact adhesive
Uzin	KE 2000S	KR 430 / KE 66	KE 2000S / WK222
Henry	695 / 422	2575 MS	2575 MS
F. Ball	F44 / F46	F73 Plus	F66
Wakol	D 3318 / D3320	MS 552 / PU 270	-

### FOAM TO FLOOR

### SHEET VINYL TO FOAM

ACOUSTIC FOAM		
Mapei	Ultrabond ECO 360 / ECO 307	Ultrabond ECO 399
Uzin	KE 2000S	KE 2000S
Henry	695 / H422	695
F. Ball	F44	F73 Plus
Wakol	MS 552	D 3120 PS made only / D3330

HORIZONTAL BOND	HORIZONTAL BOND HIGH TEMPERATURE / *EXTREME CONDITIONS	VERTICAL BOND
-----------------	--	---------------

## LUXURY VINYL TILES

### AFINITY 255 / CAMARO PUR / COLONIA PUR

Mapei	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / MS 4 LVT	Contact adhesive
Uzin	KE 2000S	KR 430 / KE 66	KE 2000S
Henry	695 / 422	2575 MS	-
F. Ball	F46 / F58 Plus	F73 Plus	-
Wakol	D 3320 / D 3120 / D 3330	MS 552 / PU 270	-

## SPORTS FLOORING

### POLYFLOR SPORT 67 PU

Mapei	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / ECO 570	Contact adhesive
Uzin	KE 2000S	KR 430 / KE 66	-
Henry	695 / 422	2575 MS	-
F. Ball	F44 / F46	F73 Plus	-
Wakol	D 3318 / 3120 / 3330	MS 552 / PU 270	-

## ESD COLLECTION

### PALETTONE SD / FINESSE SD / POLYFLOR SD /

Mapei	-	-	-
Uzin	KE 2000SL	Speak to the relevant adhesive manufacturer	-
Henry	-	-	-
F. Ball	F57	-	F60 / F66
Wakol	DL 3365 Starleit	-	-

**POLYFLOR CONDUCTIVE ROF**

<b>Mapei</b>	Speak to the relevant adhesive manufacturer	Speak to the relevant adhesive manufacturer	–
--------------	---	---	---

**WALL CLADDING****POLYCLAD PRO PU / POLYCLAD PLUS PU**

<b>Mapei</b>	–	–	Ultrabond ECO 399
<b>Uzin</b>	–	–	KE 2000S / KE 68T*
<b>Henry</b>	–	–	2575 MS / 473 Contact Adhesive
<b>F. Ball</b>	–	–	–
<b>Wakol</b>	–	–	–

# EXPONA®

## Polyflor Canada Approved Adhesives

HORIZONTAL BOND

HORIZONTAL BOND  
HIGH TEMPERATURE /  
\*EXTREME CONDITIONS

VERTICAL BOND

### LUXURY VINYL TILES

#### EXPONA DESIGN PUR / EXPONA COMMERCIAL PUR

Mapei	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / MS 4 LVT	–
Uzin	KE 2000S	KR 430 / KE 66	KE 2000S
Henry	695 / 422	2575 MS	–
F. Ball	F46 / F58 Plus	F73 Plus	–
Wakol	D 3320 / D 3120 / D333	MS 552 / PU 270	–

### LUXURY VINYL TILES

#### EXPONA SIMPLAY PUR

Mapei	ECO 307	Ultrabond G19/ MS 4 LVT	–
Uzin	KE 2000S	–	–
Henry	695 / 422	2575 MS	–
F. Ball	F41	–	–
Wakol	D9665 Tackifier	–	–

**EXPONA SIMPLAY 19dB PUR**

<b>Mapei</b>	ECO 307	Ultrabond G19/ MS 4 LVT	-
<b>Uzin</b>	KE 2000S	-	-
<b>Henry</b>	695 / 422	2575 MS	-
<b>F. Ball</b>	F46	-	-
<b>Wakol</b>	D 3320 / D 3120 / D 3330	-	-

**LUXURY VINYL TILES - SILP RESISTANT****EXPONA CONTROL PUR**

<b>Mapei</b>	Ultrabond ECO 360 / ECO 399	Ultrabond G21/ MS 4 LVT	-
<b>Uzin</b>	KE 2000S	KR 430 / KE 66	KE 2000S
<b>Henry</b>	695 / 422	2575 MS	-
<b>F. Ball</b>	F46 / F58 Plus	F73 Plus	-
<b>Wakol</b>	D 3320 / D 3120 / D333	MS 552 / PU 270	-

**HETEROGENOUS FLOORING****EXPONA FLOW PUR**

<b>Mapei</b>	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S / KE 40	KR 430	KE 2000S
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46	F73 Plus	F66
<b>Wakol</b>	D 3318 / D 3320	MS 552 / PU 270	-

## ACOUSTIC FLOORING

### SILENTFLOR 19dB PUR

<b>Mapei</b>	Ultrabond ECO 360 / ECO 399	Ultrabond G21	Water based contact adhesive
<b>Uzin</b>	KE 2000S / KE 40	KR 430 / KE 66	KE 2000S / Wk222
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46	F73 Plus	F66
<b>Wakol</b>	D 3318 / D 3320	MS 552 / PU 270	-



# Polyflor Canada Approved Adhesives

**HORIZONTAL BOND**

**HORIZONTAL BOND  
HIGH TEMPERATURE /  
\*EXTREME CONDITIONS**

**VERTICAL BOND**

## SLIP RESISTANT

### POLYSAFE VERONA PURE COLOURS PUR / POLYSAFE VERONA PUR / POLYSAFE VOGUE / POLYSAFE STANDARD PUR

<b>Mapei</b>	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S / KE 40	KR 430	KE 2000S / WK222
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46 / F58 Plus	F73 Plus	F60 / F66
<b>Wakol</b>	D 3318 / D3320	MS 552 / PU 270	-

### POLYSAFE WOOD FX PUR / POLYSAFE STONE FX PUR / POLYSAFE MOSAIC PUR

<b>Mapei</b>	Ultrabond ECO 360 / ECO 399	Ultrabond G21 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S / KE 40	KR 430	KE 2000S / WK222
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F44 / F46 / F58 Plus	F73 Plus	F60 / F66
<b>Wakol</b>	D 3318 / D3320	MS 552 / PU 270	-

## SAFETY FLOORING

### POLYSAFE APEX 55 / POLYSAFE QUATTRO PUR / POLYSAFE HYDRO / POLYAFE HYDRO EVOLVE

<b>Mapei</b>	Ultrabond ECO 399	Ultrabond G21 / G19 / MS 4 LVT	Ultrabond ECO 399
<b>Uzin</b>	KE 2000S / KE 40	KR 430 / KE 66	KE 2000S
<b>Henry</b>	695 / 422	2575 MS	2575 MS
<b>F. Ball</b>	F73 Plus	–	F49 / F60 / F66
<b>Wakol</b>	MS 552 / PU 270	–	D 3330

## ACOUSTIC FLOORING

### POLYSAFE WOOD FX ACOUSTIX PUR

<b>Mapei</b>	Ultrabond G21	Ultrabond G21	Water based contact adhesive
<b>Uzin</b>	KE 2000S / KE 40	KR 430	KE 2000S
<b>Henry</b>	2575 MS	2575 MS	2575 MS
<b>F. Ball</b>	–	F73 PLUS	–
<b>Wakol</b>	–	MS 552 / PU 270	–



Polyflor Canada provides this information only as guidance, and the legal responsibility for the supply and performance of the above adhesives shall remain the sole responsibility of the manufacturer.

Mapei  
1(800) 361-9309  
[www.mapei.com](http://www.mapei.com)

UZIN UFLOOR Systems Inc.  
1(866) 505-4810  
[www.uzin.us](http://www.uzin.us)

Henry an ARDEXGROUP Brand  
1 (888) 512 - 7339  
[www.wwhenry.com](http://www.wwhenry.com)

Wakol  
1 (800) 230 - 6456  
[www.loba-wakol.com](http://www.loba-wakol.com)

By providing this information both Polyflor Canada Inc. and Polyflor Ltd do not imply any equivalence between each of the different manufacturer's products, or that other products would prove unsatisfactory. When more than one adhesive is listed, selection should be based upon suitability to the installation environment.

Application of the named adhesives must be actioned in strict accordance with the relevant manufacturer's instructions, which may include the application of a primer in certain situations.

Site Conditions must be as described under ASTM F 710 or BS8203:2001 as appropriate.

For information regarding handling and installation and maintenance consult Polyflor Customer Technical Services on 1(905) 364-3000 or email [tech@polyflor.ca](mailto:tech@polyflor.ca) or [sales@polyflor.ca](mailto:sales@polyflor.ca)



Polyflor Canada Inc.

[www.polyflor.ca](http://www.polyflor.ca)

1(905) 364-3000

[sales@polyflor.ca](mailto:sales@polyflor.ca)

[samples@polyflor.ca](mailto:samples@polyflor.ca)

Polyflor Canada Inc

polyflorca

Polyflor Canada

polyflor\_canada