

**Product : Polyflor Pearlazzo PUR**

**Date : March 2010**

**Resistance To Chemicals**

**Page 1 of 8**

Resistance to chemicals is tested over a 24 hour contact period at room temperature (ca.21°C), followed by rinsing with cold water. Polyflor Ltd believe this simulates the worst situation where spillages are not removed immediately and are only cleaned by normal maintenance.

U - Unstained    A - Slight stain    B - Moderate stain    C - Heavy stain    E - Appearance as above plus slight surface disturbance

	Shade											
Chemical	9701	9702	9703	9704	9705	9706	9707	9708	9709	9710	9711	9712
Acetic Acid Glacial	U	U	U	U	U	U	U	U	U	U	U	U
Acetic Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Acetic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Boric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Citric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Lactic Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Nitric Acid Concentrated	U	UE	U	U	UE	A	AE	A	A	A	A	U
Nitric Acid 50% Solution	U	UE	U	U	UE	A	AE	A	A	A	A	U
Nitric Acid 10% Solution	U	UE	A	U	UE	A	AE	A	A	A	U	U
Oxalic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Perchloric Acid 60% Solution	U	UE	U	A	UE	U	UE	U	A	U	U	U
Phosphoric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Phosphoric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Pyrogalllic Acid	C	A	C	C	A	B	A	B	C	B	U	C
Sulphuric Acid Concentrated	UE	U	UE	A	U	AE	A	AE	A	AE	AE	UE
Sulphuric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sulphuric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Tannic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Tartaric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Thioglycollic Acid Concentrated	AE	BE	UE	UE	BE	UE	BE	UE	UE	UE	UE	AE

**Product : Polyflor Pearlazzo PUR**  
**Resistance To Chemicals**

**Date : March 2010**  
**age 2 of 8**

Chemical	Shade											
	9701	9702	9703	9704	9705	9706	9707	9708	9709	9710	9711	9712
Absolute Alcohol	U	U	U	U	U	U	U	U	U	U	U	U
Amidol 10% Solution	U	A	U	U	B	U	U	U	U	U	U	U
Ammonia Solution 88	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Alum 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Bichromate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Carbonate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Sulphate	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Thiocyanate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Borax 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Calcium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Calgon 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Carbon Tetrachloride	U	U	U	U	U	U	U	U	U	U	U	U
Catechol 10% Solution	A	A	UE	A	U	A	U	A	A	A	U	A
Chrome Alum 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Copper Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ferric Ammonium Citrate 10%soln	U	U	U	U	U	U	U	U	U	U	U	U
Formaldehyde 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Glycerine	U	U	U	U	U	U	U	U	U	U	U	U
Glycine 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrogen Peroxide 100	U	U	U	U	U	U	U	U	U	U	U	U
Hydroquinone 10% Solution	A	B	A	A	B	A	B	A	A	A	A	A
Hydroxylamine Hydrochloride 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Iodine 5% In Potassium Iodide Soln	C	B	C	C	B	B	B	B	C	B	C	C
Iodine Alcoholic Solution	C	C	C	C	C	C	C	C	C	C	C	C
Iron Perchlorate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Iron Sulphate 10% Solution	U	A	U	U	U	U	U	U	U	U	U	U

**Product : Polyflor Pearlazzo PUR**  
**Resistance To Chemicals**

**Date : March 2010**  
**Page 3 of 8**

Chemical	Shade											
	9701	9702	9703	9704	9705	9706	9707	9708	9709	9710	9711	9712
Lead Acetate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Magnesium Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Metol 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Mercuric Chloride 10%Solution	U	U	U	U	U	U	U	U	U	U	U	U
Methylated Spirits 10%Solution	U	U	U	U	U	U	U	U	U	U	U	U
Paraformaldehyde 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Phenol 10% Solution	U	U	U	B	U	U	U	U	U	U	U	U
Potassium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Carbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Dichromate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Ferricyanide 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Ferrocyanide 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Hydroxide 10% Solution	U	U	U	U	U	U	U	A	U	U	U	U
Potassium Iodide 10% Solution	U	A	U	U	A	A	A	A	U	A	U	U
Potassium Metabisulphite 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Oxalate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Permanganate 10% Soln	C	C	B	C	C	C	C	C	C	C	B	C
Potassium Thiocyanate 10% Soln	U	B	U	U	B	U	B	U	U	U	U	U
Silver Nitrate 10% Solution	U	A	U	U	U	U	U	U	U	U	U	U
Sodium Acetate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Bicarbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Carbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Hydroxide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Hypochlorite 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Perborate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Phosphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Sulphite 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Thiosulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U

Chemical	Shade											
	9701	9702	9703	9704	9705	9706	9707	9708	9709	9710	9711	9712
Izal Concentrated	U	U	U	U	U	U	A	U	U	U	U	U
Izal Diluted	U	U	U	U	U	U	U	U	U	U	U	U
TCP Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Dettol Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Soap Solutions	U	U	U	U	U	U	U	U	U	U	U	U
Detergent Solutions	U	U	U	U	U	U	U	U	U	U	U	U
Milk	U	U	U	U	U	U	U	U	U	U	U	U
Tea (black)	U	U	U	U	U	U	U	U	U	U	U	U
Coffee (black)	U	U	U	U	U	U	U	U	U	U	U	U
Petrol	U	U	U	U	U	U	U	U	U	U	U	U
White Spirit	U	U	U	U	U	U	U	U	U	U	U	U
Diesel Fuel	U	U	U	U	U	U	U	U	U	U	U	U
Mineral Oil (Singer)	U	U	U	U	U	U	U	U	U	U	U	U
Vegetable Oil	U	U	U	U	U	U	U	U	U	U	U	U
Anti Freeze (Bluecol)	U	U	U	U	U	U	U	U	U	U	U	U

**Product : Polyflor Pearlazzo PUR**  
**Resistance To Chemicals**

**Date : March 2010**  
**Page 5 of 8**

Resistance to chemicals is tested over a 24 hour contact period at room temperature (ca.21<sup>0</sup>C), followed by rinsing with cold water. Polyflor Ltd believe this simulates the worst situation where spillages are not removed immediately and are only cleaned by normal maintenance.

U - Unstained    A - Slight stain    B - Moderate stain    C - Heavy stain    E - Appearance as above plus slight surface disturbance

Chemical	Shade											
	9713	9715	9716	9717	9718	9719	9720	9721	9722	9723	9724	9725
Acetic Acid Glacial	U	U	U	U	U	U	U	U	U	U	U	U
Acetic Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Acetic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Boric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Citric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrochloric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Lactic Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Nitric Acid Concentrated	UE	A	U	UE	U	U	A	U	A	UE	UE	UE
Nitric Acid 50% Solution	UE	A	U	AE	U	U	A	U	A	UE	UE	AE
Nitric Acid 10% Solution	UE	A	A	UE	U	U	U	U	A	UE	UE	UE
Oxalic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Perchloric Acid 60% Solution	UE	A	U	UE	A	A	U	U	A	UE	UE	UE
Phosphoric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Phosphoric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Pyrogalllic Acid	A	C	C	B	C	C	U	C	C	A	A	B
Sulphuric Acid Concentrated	U	A	UE	U	A	A	AE	UE	A	U	U	U
Sulphuric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sulphuric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Tannic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Tartaric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Thioglycollic Acid Concentrated	BE	UE	UE	AE	UE	UE	UE	AE	UE	BE	BE	AE

Chemical	Shade											
	9713	9715	9716	9717	9718	9719	9720	9721	9722	9723	9724	9725
Absolute Alcohol	U	U	U	U	U	U	U	U	U	U	U	U
Amidol 10% Solution	A	U	U	A	U	U	U	U	U	A	A	A
Ammonia Solution 88	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Alum 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Bichromate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Carbonate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Sulphate	U	U	U	U	U	U	U	U	U	U	U	U
Ammonium Thiocyanate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Borax 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Calcium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Calgon 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Carbon Tetrachloride	U	U	U	U	U	U	U	U	U	U	U	U
Catechol 10% Solution	A	A	UE	U	A	A	U	A	A	A	A	U
Chrome Alum 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Copper Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Ferric Ammonium Citrate 10% soln	U	U	U	U	U	U	U	U	U	U	U	U
Formaldehyde 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Glycerine	U	U	U	U	U	U	U	U	U	U	U	U
Glycine 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Hydrogen Peroxide 100	U	U	U	U	U	U	U	U	U	U	U	U
Hydroquinone 10% Solution	B	A	A	B	A	A	A	A	A	B	B	B
Hydroxylamine Hydrochloride 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Iodine 5% In Potassium Iodide Soln	B	C	C	B	C	C	C	C	C	B	B	B
Iodine Alcoholic Solution	C	C	C	C	C	C	C	C	C	C	C	C
Iron Perchlorate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Iron Sulphate 10% Solution	A	U	U	U	U	U	U	U	U	A	A	U

**Product : Polyflor Pearlazzo PUR**  
**Resistance To Chemicals**

**Date : March 2010**  
**Page 7 of 8**

Chemical	Shade											
	9713	9715	9716	9717	9718	9719	9720	9721	9722	9723	9724	9725
Lead Acetate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Magnesium Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Metol 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Mercuric Chloride 10%Solution	U	U	U	U	U	U	U	U	U	U	U	U
Methylated Spirits 10%Solution	U	U	U	U	U	U	U	U	U	U	U	U
Paraformaldehyde 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Phenol 10% Solution	U	U	U	U	B	B	U	U	U	U	U	U
Potassium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Carbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Dichromate 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Ferricyanide 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Ferrocyanide 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Hydroxide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Iodide 10% Solution	A	U	U	A	U	U	U	U	U	A	A	A
Potassium Metabisulphite 10% Soln	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Oxalate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Potassium Permanganate 10% Soln	C	C	B	C	C	C	B	C	C	C	C	C
Potassium Thiocyanate 10% Soln	B	U	U	B	U	U	U	U	U	B	B	B
Silver Nitrate 10% Solution	A	U	U	A	U	U	U	U	U	A	A	A
Sodium Acetate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Bicarbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Bromide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Carbonate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Chloride 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Hydroxide 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Hypochlorite 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Perborate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Phosphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Sulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Sulphite 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U
Sodium Thiosulphate 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U

Chemical	Shade											
	9713	9715	9716	9717	9718	9719	9720	9721	9722	9723	9724	9725
Izal Concentrated	U	U	U	A	U	U	U	U	U	U	U	A
Izal Diluted	U	U	U	U	U	U	U	U	U	U	U	U
TCP Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Dettol Concentrated	U	U	U	U	U	U	U	U	U	U	U	U
Soap Solutions	U	U	U	U	U	U	U	U	U	U	U	U
Detergent Solutions	U	U	U	U	U	U	U	U	U	U	U	U
Milk	U	U	U	U	U	U	U	U	U	U	U	U
Tea (black)	U	U	U	U	U	U	U	U	U	U	U	U
Coffee (black)	U	U	U	U	U	U	U	U	U	U	U	U
Petrol	U	U	U	U	U	U	U	U	U	U	U	U
White Spirit	U	U	U	U	U	U	U	U	U	U	U	U
Diesel Fuel	U	U	U	U	U	U	U	U	U	U	U	U
Mineral Oil (Singer)	U	U	U	U	U	U	U	U	U	U	U	U
Vegetable Oil	U	U	U	U	U	U	U	U	U	U	U	U
Anti Freeze (Bluecol)	U	U	U	U	U	U	U	U	U	U	U	U